



John Deere Operations Center Integration

IntelliCulture Onboarding Guide • MTG

These are the steps to enable the John Deere → IntelliCulture integration, which gives IntelliCulture access to your machine locations in John Deere Operations Center. Please let us know if you have any questions.

Step 1: Make a Connection to IntelliCulture

1. Make a connection to IntelliCulture's John Deere application using the following link: [Connections](#).
2. A pop-up will appear that should look like the image below (if nothing comes up, check whether pop-ups are blocked in your browser). Choose your organization, then click "SAVE."

Choose your organization, then click SAVE.

Step 2: Add IntelliCulture as a Staff Member

1. In Ops Center, go to Setup → Team and add the email dev@intelliculture.ca as a staff member.
2. On the Team page, click Add → Staff Member.
3. Enter the email. The next page will list the permissions — set each category as follows (access levels range from 0 to 3).

Category	Access Level	Notes
Equipment	Level 1 (Required)	Gives us access to machine locations.
Organization	Level 1 (Suggested)	Lets us easily confirm our user is set up correctly in your account. Entirely optional.
Locations	Level 1 (Recommended)	Helps us validate we have all the zones from the provided shapefiles. This is not a replacement for sending shapefiles.
Work	Level 0	Can be left at Access Level 0.
Financial	Level 0	Can be left at Access Level 0.

Permission Details

Equipment – Level 1 (Required)

For the integration we require Equipment level 1; this will give us access to machine locations.

Equipment ^

Show Full Details Access Level 0 1 2 3

- ✓ View Equipment
Permission to view equipment details, including location, driving directions, alerts, offsets, and maintenance plans.
- ⊗ Edit Equipment
Permission to add equipment and edit equipment nickname, offsets, modem settings, geofences and curfews, and maintenance plans.
- ⊗ Manage Equipment
Permission to manage equipment and related data.

Grant Additional Permissions

- ☐ Remote Display Access
Permission to remotely access compatible John Deere displays.
 - ☐ Remote Display Control
Permission to remotely control compatible John Deere displays.
- ☐ Setup File Creator, Products, and Wireless Data Transfer
Permission to create, manage, send, and receive files to a John Deere display (wirelessly or via USB).

Organization – Level 1 (Suggested, optional)

We suggest Organization level 1 so we can easily confirm our user is set up correctly in the account. This is entirely optional.

Organization ^

Show Full Details Access Level 0 1 2

- ✓ View Staff, Operators, and Partners
Permission to view organization staff, operators, and partners, including their access levels.
- ⊗ Manage Staff, Operators, and Partners
Permission to add, edit and delete organization staff, operators, partners, and dealers and edit their access levels.

Grant Additional Permissions

- ☐ Share Organization Data with Connected Software Companies
Permission to connect to and share this organization's data with Connected Software companies.

Locations – Level 1 (Recommended)

We also recommend Locations level 1, which helps us validate we have all the zones from the provided shapefiles. This is not a replacement for sending the shapefiles.

Locations



[Show Full Details](#)

Access Level

0

1

2

3

✓ View Locations and Products

Permission to view products and equipment location information, including driving directions, boundaries, and guidance tracks.

⊗ Analyze Production Data

Permission to analyze production and agronomic data.

⊗ Manage Locations, Products, and Production Data

Permission to edit and delete products, locations, and production and agronomic data.

Work & Financial – Level 0

The Work and Financial permissions can be left at Access Level 0.

Work



[Show Full Details](#)

Access Level

0

1

2

⊗ View Work Plans

Permission to view work plans, products, and tank mixes.

⊗ Manage Work Plans

Permission to create, edit, and delete work plans, products, and tank mixes.

Financial



[Show Full Details](#)

Access Level

0

1

2

⊗ View Financials

Permission to view financial information for this organization.

⊗ Manage Financials

Permission to create and delete financial information, including costs and revenue.

IntelliCulture

www.intelliculture.com